

Oticon Hearing Instruments and DAI/FM compatibility Overview 2005

910 53 310 00/04.05 printed in Denmark

Hearing Aid	DAI Adaptor		FM Adaptor	FM receiver
	Low Level Input	High Level Input	FM Receivers	Universal and dedicated LEXIS receivers
 <p>Oticon Syncro, Oticon Tego Pro, Oticon Tego</p>	Bodyworn FM systems e.g. Solaris	TV, stereo, MP3 player, CD player, Computer	Adaptor for LEXIS receivers and other ear-level plug-in receivers	Universal and dedicated LEXIS receivers
 <p>Adapto, Gaia, Atlas Plus, Direct, GO, DirectDigiFocus II (all V2*), DigiLife.com (all V2*) * if not marked V2 on battery door, aid must be sent to Oticon for modification.</p>	AP 800 399-51-480-00* Transparent  * includes tool for adaptor lock * input levels are set manually	FM 8 399-51-470-00* Transparent  * includes tool for adaptor lock	LE-U 140-22-xxx-xx Grey 	
 <p>Sumo DM, Sumo XP, Sumo E, Swift 120+</p>	AP 501 399-51-440-03* Transparent  * includes tool for making hole in battery door	AP 502 399-51-441-04* Transparent  * includes tool for making hole in battery door	FM 5 399-51-170-07* Transparent  * includes tool for making hole in battery door	LE-5 140-32-xxx-xx Grey/Transparent  * includes tool for making hole in battery door
 <p>Multifocus Classic, 380P, 390PL, E35, E35F, E37, E37F, E38P, E39PL</p>	AP 201 399-50-360-05 Beige 	AP 202 399-50-370-07 Beige 	FM 3 399-51-180-09* Transparent  * includes tool for making hole in battery door	LE-U 140-22-xxx-xx Grey 
 <p>DigiFocus II Super Power, 300P, E30P, E30V, E31V</p>	AP 501 399-51-440-03* Transparent  * includes tool for making hole in battery door	AP 502 399-51-441-04* Transparent  * includes tool for making hole in battery door	FM 5 399-51-170-07* Transparent  * includes tool for making hole in battery door	LE-5 140-32-xxx-xx Grey/Transparent  * includes tool for making hole in battery door

Hearing Aid	DAI Adaptor		FM Adaptor	FM receiver
	Low Level Input	High Level Input	FM Receivers	Universal and dedicated LEXIS receivers
 <p>DigiFocus, DigiLife, Primofocus, Personic (except 430)</p>	AP 401 399-50-276-02 Transparent 	AP 402 399-50-286-04 Transparent 	FM 4 399-51-130-08* Transparent  * includes tool for making hole in battery door	LE-U 140-22-xxx-xx Grey 
 <p>Atlas, Atlas Plus, GO, Ergo, Swift</p>	AP 600 399-50-460-06* Transparent  * includes tool for adaptor lock * input levels are set manually	FM 6 399-50-450-04* Transparent  * includes tool for adaptor lock	LE-U 140-22-xxx-xx Grey 	
 <p>Sumo DM, Sumo XP, Sumo E, Swift 120+</p>	AP 700 399-50-900-08* Grey  * input levels are set manually	FM 7 399-50-920-02 Grey 	LE-7 140-30-xxx-xx Grey 	
 <p>Multifocus Classic, 380P, 390PL, E35, E35F, E37, E37F, E38P, E39PL</p>	AP 301 399-50-340-00 Beige 	AP 302 399-50-350-03 Beige 	FM 3 399-51-180-09* Transparent  * includes tool for making hole in battery door	LE-U 140-22-xxx-xx Grey 
 <p>CI Processors from various manufacturers</p>			FM-CI Cochlear implant adaptor 140-08-110-00 	LE-U 140-22-xxx-xx Grey 